

Visionary-T Mini CX

3D machine vision

EN



SICK

Visionary-T Mini CX

Valid for the following part number:
1112649, 1132065



NFPA79 applications only.
Adapters providing field
wiring leads are available.
Refer to the product information.
Enclosure Type 1.

Australia Phone	+61 (3) 9457 0600 1800 33 48 02 – tollfree
Austria Phone	+43 (0) 2236 62288-0
Belgium/Luxembourg Phone	+32 (0) 2 466 55 66
Brazil Phone	+55 11 3215-4900
Canada Phone	+1 905.771.1444
Czech Republic Phone	+420 234 719 500
Chile Phone	+56 (2) 2274 7430
China Phone	+86 20 2882 3600
Denmark Phone	+45 45 82 64 00
Finland Phone	+358-9-25 15 800
France Phone	+33 1 64 62 35 00
Germany Phone	+49 (0) 2 11 53 010
Greece Phone	+30 210 6825100
Hong Kong Phone	+852 2153 6300
Hungary Phone	+36 1 371 2680
India Phone	+91-22-6119 8900
Israel Phone	+972 97110 11
Italy Phone	+39 02 27 43 41
Japan Phone	+81 3 5309 2112
Malaysia Phone	+603-8080 7425
Mexico Phone	+52 (472) 748 9451

Netherlands Phone	+31 (0) 30 204 40 00
New Zealand Phone	+64 9 415 0459 0800 222 278 – tollfree
Norway Phone	+47 67 81 50 00
Poland Phone	+48 22 539 41 00
Romania Phone	+40 356-17 11 20
Singapore Phone	+65 6744 3732
Slovakia Phone	+421 482 901 201
Slovenia Phone	+386 591 78849
South Africa Phone	+27 10 060 0550
South Korea Phone	+82 2 786 6321/4
Spain Phone	+34 93 480 31 00
Sweden Phone	+46 10 110 10 00
Switzerland Phone	+41 41 619 29 39
Taiwan Phone	+886-2-2375-6288
Thailand Phone	+66 2 645 0009
Turkey Phone	+90 (216) 528 50 00
United Arab Emirates Phone	+971 (0) 4 88 65 878
United Kingdom Phone	+44 (0)17278 31121
USA Phone	+1 800.325.7425
Vietnam Phone	+65 6744 3732

Detailed addresses and further locations at www.sick.com

Disclaimer

SICK uses standard IP technology in its products, for example IO-Link. The emphasis is placed on availability of products and services. SICK always assumes that the integrity and confidentiality of the data and rights affected by the use of the aforementioned products will be ensured by the customer.

In all cases, appropriate security measures, such as network separation, firewalls, virus protection, and patch management, must be taken by the customer based on the situation in question.

Cybersecurity

To protect against cybersecurity threats, it is necessary to continuously monitor and maintain a comprehensive and holistic cybersecurity concept. A suitable concept comprises organizational, technical, procedural, electronic, and physical levels of defense and provides suitable measures for different types of risks. Products and solutions from SICK must be viewed as a component of this concept.

You can find more information about cybersecurity at:
www.sick.com/psirt

Safety

- Visionary-T Mini CX does not constitute personal protection equipment in accordance with the respective applicable safety standards for machines.
- The mounting, electrical installation and configuration of the device must only be carried out by professionally qualified personnel.
- When mounting and electrical installation work is being carried out, always comply with standard operating procedures, and applicable health and environmental regulations.
- The camera is not suitable for use in explosion-hazardous areas.
- When installing the device, always consider the electrical connected loads.
- Replace faulty or damaged cables and male connectors immediately.
- Replace damaged or faulty components immediately and in consultation with SICK AG.
- When mounting the device, it is imperative that you use suitable mounting equipment and that you consider their specific tightening torques. The mounting equipment must be self-locking or secured appropriately.
- Ensure a constant voltage supply to the device within the set parameters.
- Operate the 3D vision camera only within the set operating parameters.
- Regularly check that the 3D vision camera is functioning properly.
- The infrared beams of the laser illumination unit do not pose a danger to the human eye if the 3D vision camera is operated within the specified parameters.
- Structural modifications to the 3D vision camera are strictly forbidden!
- During mounting, ensure there are no attachment parts in the detection volume of the 3D vision camera.
- The 3D vision camera must not be mounted behind a transparent screen since this will affect the system properties.
- If heat dissipation is inadequate, the housing temperature can exceed the specified range. Ensure an adequate heat dissipation (see accessories) and, if necessary, adjust the device configuration.
- The 3D vision camera can be affected by external light sources, or interfere with other sensors (e.g., laser scanners) due to the active laser illumination unit.

CAUTION

Optical radiation: Laser class 1

The accessible beam from the laser illumination unit integrated into the device does not pose a danger when exposed directly for up to 100 seconds. It may pose a hazard to the eyes and skin in the event of incorrect use.

- Do not open the housing. Opening the housing may increase the level of risk.
- Applicable national regulations regarding laser protection must be observed.

Scope of delivery

- Visionary-T Mini CX (3D vision camera)
- Quickstart

Product features

- Output of 3D image data via a Gigabit Ethernet interface
- Meets industrial requirements for data security and reliability
- Easy mounting and commissioning
- 3D data acquisition at up to 30 frames per second (fps)
- Convenient API connection for using the 3D vision camera in specialist applications
- Configuration and activity recording via the SOPAS Engineering Tool (SOPAS ET) on a computer

Overview

Visionary-T Mini CX is a 3D vision camera based on the time-of-flight (ToF) principle. It provides real time 3D data at up to 30 frames per second (fps).

The SOPAS ET software can be used to configure the 3D vision camera and visualize the data.

SOPAS ET can be used to define and configure different setups.

Once configured, the 3D vision camera runs in stand-alone operation. It continuously provides the outputs via the configured interface.

To use the 3D vision camera, perform the following steps:

1. Complete the mechanical and electrical setup.
2. Install SOPAS ET.
3. Connect the 3D vision camera to SOPAS ET.
4. Configure the 3D vision camera.

Completing the mechanical and electrical setup and installing SOPAS ET

Mount the device using the accessories provided **F**.

1. Prepare the mounting location in accordance with the dimensional drawing **A**.
2. Mount the 3D vision camera in the proper alignment for the desired detection volume. Ensure that the detection volume is bordered by a surface **D**. To avoid optical interference, ensure that the 3D vision camera is not on the same optical axis as other opto-electronic sensors when mounting it.
3. Connect the 3D vision camera via the Ethernet interface directly to your computer, or to the network to which your computer is connected.
4. Use the system plug of the 3D vision camera to connect the voltage supply and signal transmission **B**.
5. Install SOPAS ET by running the installation file (as administrator).
6. Follow the instructions of the installation program.

Connecting to SOPAS ET

SOPAS ET is a software program of SICK AG. It has been developed for Windows systems for monitoring and configuring devices.

Connecting SOPAS ET to the 3D vision camera:

1. Ensure the 3D vision camera is switched on and connected to the computer or the same network.
2. Start **SOPAS ET**.
3. SOPAS ET automatically attempts to identify connected devices when it starts. If the 3D vision camera is in the same network segment, the camera is displayed in the list of devices found.
4. Click the 3D vision camera in the list of available devices. Add the 3D vision camera to the project. The required device file can be installed directly from the internal storage device of the 3D camera.
5. Double-click the 3D vision camera in the project list.

The device window opens.



Connecting to SOPAS ET

- If SOPAS ET cannot establish a connection to the camera, the connection assistant, which can be used to change the IP address, is displayed.

Note: The default IP address for the 3D vision camera is 192.168.1.10

- If the device is not listed, click **Search for devices** to open the connection wizard.

You can find additional information relating to the connection assistant in the online help for SOPAS ET.


Pre-installing the device driver (alternative installation)

1. Start **SOPAS ET**. Open the **Device Catalog** tab.
2. Open the device driver manager . Click on **Install**.
3. Select the **From a data card** option. Search for the device file.
4. Select the file. Follow the instructions of the installation wizard.

Toolbar in the sensor application


The visualization and control of the 3D vision camera is carried out in SOPAS ET via the **Visual settings**, the **Configuration**, and the toolbar. Two different display options are available for this.

2D view



The 2D view shows a grayscale image of the captured scene. This can help you to position the 3D vision camera correctly, or to bring specific objects into the field of view.

3D view



The 3D view provides a three-dimensional point cloud visualization. The visualization depends on the specific camera settings selected. The color scale and color range in both the 2D and 3D viewer can be customized in the view options.

SOPAS icons

- Selection arrow**
Select individual points from the cluster of points and mark them.
- Move**
Move the displayed image section left or right as well as up or down
(Also: Shift + Left Click + Move).
- Rotate**
Rotate the displayed image section around the current image center point
(Also: Ctrl +Left Click + Move).
- Zoom**
Enlarge or reduce the currently displayed image section
(Also: scroll wheel forward/back).
- Display options**
Switch between the individual display forms of the collected points.
- Reset**
Reset the perspective to default.
- Select viewing angle**
Select different pre-configured viewing angles. To select a viewing angle, click the respective arrowhead.
- Still image**
Interrupts the replay of the camera data, for example to store a still image.

Toolbar in the sensor application


- Log into the device**
After logging in, you can edit camera parameters and access detailed status information.
- Log out of the device**
Log out to prevent unauthorized access to the camera.
- Read device parameters.**
Reads the current camera parameters. Updates the SOPAS parameters.
- Write camera parameters.**
Transfers the current SOPAS parameters to the camera.
- Save setup.**
Saves the configured setup permanently on the device.
- Record**
Starts and stops the stream recording, which is saved as a *.ssr file.
- Replay**
Opens a new window to replay an *.ssr file stored on a data card.
- Save 3D point cloud.**
Saves the 3D point cloud as a *.pcd file
- Trigger next image.**
Displays the next triggered image in the trigger mode.
- Question mark**
The "question mark" icon can be used to display additional information and help for each parameter.

Configuring and visualizing the 3D vision camera

SOPAS ET can, amongst other things, be used to carry out diagnostics and visualizations. You can configure further settings via the **Authorized Customer** or **Service** user level.

Note: You can find information on how to change the user level in the online help for SOPAS ET. The passwords for the user levels can be obtained from the customer service department.

1. Switch on the 3D vision camera. Connect it to SOPAS ET (see "Connecting to SOPAS ET").
 2. Click the "Visual settings" step to begin configuring the settings for your use case.
 3. In the settings overview, click on **Mounting settings**:
The center of the disc with the status LEDs is the origin of the coordinates (x|y|z = 0|0|0).
Edit the parameters to transform the camera data into the world coordinate system.
 4. Now close the **Mounting settings**.
 5. Use the image and recording settings to configure the format as well as the recording cycle of the data.
 6. Configure the data filter in the Filter settings.
 7. Open the display control.
 8. Use the display control to adjust the output so you can achieve as clear outputs as possible under real conditions.
- Note:** The displayed raster represents the floor (as x/y reference plane). The 3D camera is aligned to this using the Mounting settings.



Configuring and visualizing the 3D vision camera

9. If noticeable image artifacts are present, you can if necessary adjust the filter or image and capture settings. This enables you to eliminate the artifacts as far as possible.
10. We recommend permanently saving the settings.
Note: The parameters can be saved using **Device – Export** or loading using **Device – Import**.
11. "Configuration" can be used to configure the actuation of the digital outputs via the camera.
12. Open the other available views to obtain detailed information on the operational status and characteristics of the camera (temperature, operating hours counter, etc.).
13. After entering the required information and configuration of the sensor is complete, we recommend permanently saving the setup. SOPAS ET can then be closed.

Programming the application

The Visionary-T Mini CX is normally integrated into customer-specific applications and communicated with via an API interface.

The settings selected under visualization in SOPAS ET can act as reference values and default settings.

A detailed description of the API interface and example codes for connecting to the 3D camera, I/O communication, and further examples are available on the product page.

The Visionary-T Mini CX provides continuous 3D data to the data interface. For this reason, ensure the communication interface is designed for large data quantities, and ensure adequate storage space is available.

Service and maintenance

The 3D camera contains no inner parts that the user needs to have serviced.

- Check the screw connections and terminals regularly.
- Clean the housing using a soft cloth. Either use a dry cloth, or dampen it with lukewarm water and a small amount of mild cleaning agent.
- Ensure adequate heat dissipation to guarantee the availability of the device in continuous operation (see accessories).

Additional information

More information can be found on the product page.

It can be accessed via the SICK Product ID:

[pid.sick.com/\(P/N\)/\(S/N\)](http://pid.sick.com/(P/N)/(S/N))

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if specified).

The following information is available depending on the product:

- Data sheets
- This document in all available language versions
- CAD files and dimensional drawings
- Certificates (e.g., declaration of conformity)
- Other publications
- Software
- Accessories

For additional information, visit supportportal.sick.com or see the online help for SOPAS ET.

Please contact your local sales office in the event of any support queries.

Software licenses

SICK uses open source software which is published by the rights holders under a free license. Among others, the following license types are used: GNU General Public License (GPL version 2, GPL version 3), GNU Lesser General Public License (LGPL), MIT license, zlib license and licenses derived from the BSD license.

This program is provided for general use without warranty of any kind. This warranty disclaimer also extends to the implicit assurance of marketability or suitability of the program for a particular purpose.

See the GNU General Public License for more information.

You can obtain the source code for these software components from us within three years of delivery of the product by sending an inquiry to our customer service department at the following email address:
foss.compliance@sick.de.

For the license text, see www.sick.com/licensetexts. Printed copies of the license texts are also available on request.

